

SGA™ CHEEK RISER INSTALLATION INSTRUCTIONS

⚠ WARNING: BEFORE STARTING, MAKE SURE THE WEAPON IS UNLOADED, THE CHAMBER IS EMPTY, AND THE SAFETY ENGAGED.




STEP 1: LOP SLIDER REMOVAL

Remove the *Butt-Pad Slider* by loosening the *Slotted Head Slider Screw* and removing. The *Slider* can then be pulled out of the back of the stock.




STEP 2: REMOVE ORIGINAL CHEEK RISER

Lift and remove *Cheek Riser* away from *Stock Body*.



STEP 3: INSTALL CHEEK RISER

Place desired *Cheek Riser* onto *Stock Body* hooking front into *Stock Body* first, then lowering rear into place.



STEP 4: REINSTALL BUTT-PAD SLIDER

Re-install *Buttpad Slider* by sliding back into *Stock*, with tab on front of *LOP Spacer* or *Buttpad Slider* fitting into slot on rear of *Cheek Riser*. Re-install *Slider Screw* and tighten with screwdriver.

Caution: Do not over tighten. Over tightening can cause damage to the Stock or Slider.